

SET and RESET dependency (S- and R-dependency)

SET and RESET dependencies are used if it is necessary to specify the effect of the combination  $R = S = 1$  on a bistable element. These dependencies should not be used if such specification is not necessary. For an example of application, see the remark with symbol S01665 (12-42-07).

Affecting S- and R-inputs can affect only outputs.

See A00283\_Illustration\_EN.pdf