

No	Symbol	Description
11-xx-xx		Control-switch station
11-xx-xx		Control-switch station with signallamp
11-xx-xx		Pusch-button with flexible connection
11-xx-xx		Pusch-button with flexible connection, multifunction
11-xx-xx		Pedaloperated switch, singlepole
11-xx-xx		Bolt switch, burgler alarm
11-xx-xx		Vibration switch, burgler alarm
11-xx-xx		Glass break detector (window foil), burgler alarm
11-xx-xx		By-pass switch for alarm