TRANSMISSION dependency (X-dependency)

TRANSMISSION dependency is used to indicate controlled transmission paths between affected ports (inputs, outputs and/or input-outputs). Unless otherwise indicated, the transmission paths are bidirectional. The TRANSMISSION dependency provides a way of symbolizing simple analogue switches and it enables more complicated devices to be depicted in a concise manner.

See A00281_Illustration_EN.pdf